

R-1535

**C.F.-COMPETITION STRUT TOWER BRACE C2/C4, RS AMERICA,  
& 993 MODELS  
INSTALLATION INSTRUCTIONS**

**NOTE:** This brace is designed for competition vehicles with aftermarket spherical upper strut bearings. This brace will interfere with factory upper strut mounts.

Step 1.

There are (4) 13mm. nuts per side. Remove the (2) front nuts and washers from each side.

Step 2.

Install end brackets (2) as shown below. Torque nuts to factory specifications.

Step 3.

Install one end of the cross tube using the hardware supplied.

Step 4.

Adjust the length of the tube by holding the unattached rod end and rotating the tube. Adjust until the fastener slides freely through the bracket and the clevis. Install fasteners.

Step 5.

We recommend pre-loading the brace by rotating the tube in the direction which lengthens it ½ of a turn. \*Be careful, you can rotate the tube several turns with little resistance and put enormous force on the strut towers, therefore do not exceed ½ turn from the neutral position!

Step 6.

Tighten the jam nuts on the rod ends against the cross tube.

Performance driving events are by nature potentially hazardous to your health. Brey-Krause Mfg. Co. Inc. shall not be liable for injury, consequential, or other types of damages resulting from the use or misuse of our products. Proper installation of these parts is critical and should only be done by a professional shop.

